

*Please give credit where credit is due! This DIY was completed ENTIRELY by the hardest working VW Vortex moderator on the site!! Gary Thompson, Ph.D. - vortex ID VGRT6, email address vgrt6@yahoo.com. Please make sure to say thanks to Gary, and if you ever see him at a bar, buy em a beer. These DIY's are more complete than anything Bentley has ever written!!*

I found this list in a thread and thought it would be easier to locate in a search with a better title. Thanks to Jackal for posting this in the following thread (<http://forums.wvortex.com/zerothread?id=227321>).

## MKIV FUSE LIST

1. Washer nozzle heaters, glove compartment light, memory seat control module (10A).
2. Turn signal lights (10A).
3. Fog light relay, instrument panel light dimmer switch (5A).
4. License plate light (5A).
5. Comfort system, cruise control, Climatronic, A/C, heated seat control modules, automatic day/night interior mirror, control module for multi-function steering wheel, control unit in steering wheel (7.5A).
6. Central locking system (5A).
7. Back-up lights, speedometer vehicle speed sensor (VSS) (10A).
8. Open
9. Anti-lock brake system (ABS) (5A).
10. Engine control module (ECM): gasoline engine (10A); diesel engine, Model Year 2000 > (5A).
11. Instrument cluster, shift lock solenoid (5A).
12. Data Link Connector (DLC) power supply (7.5A).
13. Brake tail lights (10A).
14. Interior lights, central locking system (10A).
15. Instrument cluster, transmission control module (TCM) (5A).
16. A/C clutch, after-run coolant pump (10A).
17. Open.
18. Headlight high beam, right (10A).
19. Headlight high beam, left (10A).
20. Headlight low beam, right (15A).
21. Headlight low beam, left (15A).
22. Parking lights right, side marker right (5A).
23. Parking lights left, side marker left (5A).
24. Windshield and rear window washer pump, windshield wiper motor (20A).
25. Fresh air blower, Climatronic, A/C (25A).
26. Rear window defogger (25A).
27. Motor for rear windshield wiper (15A).
28. Fuel pump (FP) (15A).
29. Engine control module (ECM) gasoline engine (15A); diesel engine (10A).
30. Power sunroof control module (20A).
31. Transmission control module (TCM) (20A).
32. Injectors: gasoline engine (10A); diesel engine (15A).
33. Headlight washer system (20A).
34. Engine control elements (10A).

35. 12 V power outlet (in luggage compartment) (30A).
36. Fog lights (15A).
37. Terminal (86S) on radio, Instrument cluster (10A).
38. Central locking system (with power windows), luggage compartment light, remote/fuel tank door, motor to unlock rear lid (15A).
39. Emergency flashers (15A).
40. Dual tone horn (20A).
41. Cigarette lighter (15A).
42. Radio (25A).
43. Engine control elements (10A).
44. Heated seats (15A).

Fuse arangements in fuse bracket/battery:

- S162. Glow plugs (coolant) (50A).
- S163. Fuel pump (FP) relay/glow plug relay (50A).
- S164. Coolant fan control (FC) control module/coolant fan (40A).
- S176. Relays panel interior (110A).
- S177. Generator (GEN) (90 Amp.) (110A).  
Generator (GEN) (120 Amp.) (150A).
- S178. ABS (hydraulic pump) (30A).
- S179. ABS (30A).
- S180. Coolant fan (30A).